




Quick Start Guide

Dash Camera T5
Version 1.0.0


Packing List



1

Camera Introduction

i Cut off the power supply before installing TF card.




- | | |
|-------------------|-------------------------------|
| 1. Reset Button | 6. Power Supply Interface |
| 2. Lens | 7. Reversing Camera Interface |
| 3. Bracket | 8. TF Card Slot |
| 4. Speaker | 9. GPS Antenna Interface |
| 5. Power Button * | |

* Power Button: Short press the button to lock the screen, long press to shut down.


2

Camera Installation


Installing dash camera




① Slide out the lens of the dash camera.



② Clip the dash camera to the rear view mirror. Cover the strap buckles on the dash camera to fix the dash camera on the rearview mirror.



③ Lay cable as shown in the figure.





④ Insert the car charger into the cigarette lighter and connect the power cable of the camera.

3

Installing reversing camera

① Install camera on the appropriate location near the license plate. Connect the reversing camera to the dashcam and lay cable as shown in the figure.



② Connect the power cable of the reversing camera into the reversing camera interface and connect the red reversing line to the reverse light power line of the car.

③ Adjust the lens to ensure that the lens is level with the ground.

- i**
- The installation of the dash camera and reversing camera is only for reference, and the actual vehicle shall prevail.
 - It is recommended to install the camera by professionals.

4

Operating with App

① Scan the following QR code to download and install the App.



iOS



Android

② Run the App, select and connect Wi-Fi of the camera.

③ After successful connection to the camera, you can set parameters and real-time preview video.

Factory Default Information
Wi-Fi: DH_T5_L1_XXXXXX
Password: 12345678

5

Functions

Start and shutdown
Connect the dash camera to the vehicle power supply through cigarette lighter. When the vehicle engine starts, the dash camera will start and record. After the engine shuts down, the dash camera shuts down.

Video Recording
The camera supports normal recording and emergency recording. When recording, you can set whether to collect sound or not in App.

Voice Control
The dash camera supports voice control (Only supports English). After the device is turned on, directly say the command to trigger the corresponding function.

Show front camera	Display the front video image.
Turn off display	Lock the screen.
Turn off recording	Stop recording.
Show rear camera	Display the rear video image.
Open screen	Unlock the screen.
Open recording	Start recording.
Lock the video	The dash camera will lock the current video.

Technical Specification

Parameter	Description
Camera Pixel	4K
Frame Rate	Front: 3840×2160P@25fps; 2560×1440P@25fps Rear: 1920×1080P@25fps
Iris	Front: F1.5 Rear: F1.8
Field of View	Front: D=123°, H=105°, V=56° Rear: D=136°, H=111°, V=58°
Storage	1 TF card port, supports 16 GB-128 GB.
G-Sensor	Built in, supports locking video after collision.
GPS	Support
Wi-Fi	Support
Sound Recording	Support
WDR	Support
Noise Reduction	2D/3D NR
Power Supply	DC 5V $\Rightarrow$ 3A
Operating Temperature	-20°C to 70°C(-4°F to 158°F)
Operating Humidity	95%(MAX)
Size	256mm×73mm×40mm(10.08"×2.87"×1.57")
Weight	Approx. 338.4g (0.746 lb)

FAQ

If some functions do not work properly or the relevant setting values are changed, try restarting the camera or restoring the factory settings.

Q: The dash camera is frequently powered off?
A:

- Confirm whether the power cable of the dash camera is connected normally and whether each port is loose.
- Ensure that the power cable of the dash camera is normal and free from damage.

Q: The dash camera can not be started?
A:

- Confirm whether the engine is started and whether the power supply is normal.
- Confirm whether the cigarette lighter is loose.

Q: The dash camera is easy to fall off?
A:

- Clean the windshield before installation.
- Check whether 3M adhesive and electrostatic sticker are firmly attached.

Q: The video is blurred?
A:

- Check whether the lens protective film is removed.
- Check whether the windshield or camera lens is dirty.

Q: The dash camera cannot record normally?
A:

- Confirm that the dash camera is started.
- Confirm whether the TF card is inserted.
- Confirm whether the TF card is normal: whether the TF card is formatted and whether the service life of the TF card is too long. Replace the TF card.

Q: The mobile phone cannot be connected to the dash camera?
A:

- Confirm that the correct App has been installed on the mobile phone.
- Restart the dash camera and App.

Q: The mobile phone cannot play the video?
A: The situation may be related to the player or system of the mobile phone. Please put the TF card into the computer to read and play.

Scan the QR code to get multi-language QSG and User's Manual of GPS Track Playback.



Multi-language QSG



User's Manual of GPS Track Playback

About the Guide

- This manual is for reference only. The operation of the actual product shall prevail if there is any inconsistency.
- All the designs and software are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local customer service if there is any problem when using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

